



RECOMMENDATION for WOOD CONSTRUCTION

DAMP ROOMS AND WET AREAS

In the case of moisture-sensitive load-bearing parts (wooden ceiling construction), a vapor barrier open to diffusion with high draught, at shell level, is recommended.

In normal rooms (without regular water load) it is not necessary to install a vapor barrier.



WALLS

A vapor barrier does not have to be used for wooden construction walls. For gypsum plasterboard walls with a ThermoWhite installation thickness > 20 cm, a high draught by means of a vapor barrier, sealing coat or similar is recommended.

